



Reimagining Probiotics Protection with Breakthrough Active Material Science Technologies






François Bidet | VP Business Development
Geneva, Switzerland | May 11th, 2022

About Aptar CSP Technologies

- Joined **AptarGroup** in August 2018
- Premier active **material science solutions expert** delivering innovative, highly-engineered, **active packaging** solutions
- Headquarters Auburn, Alabama, USA, with **+500** dedicated employees in **4** countries
- **+1.2** billion components manufactured annually, **4** manufacturing locations worldwide (US, France & China)
- **+ 600** worldwide patents
- **ISO-9001**, **ISO-13485** and **ISO-14001** certified



Broad Therapeutic Expertise



Platform Technology Serving Broad Therapeutic Areas

Oral Solid Dose

Dermal Drug Delivery

Drug Delivery Systems

Diagnostics

Probiotics

Medical Device & Implants



Immunodeficiency Treatment

Hormone Patch/
MAP Device

Inhalation/ Nasal
Drug Delivery

Blood Glucose
Testing/COVID
Testing


Dietary
Supplement

Implant
Neurostimulator



Packaging of Probiotics Formulations Constraints

- Most probiotics strains are sensitive to moisture and temperature
- Some strains like Next Generation Probiotics (NGPs) are also very sensitive to oxygen and light
- Traditional packaging like bottles or coldform (alu/alu) blisters do not address initial moisture content
- Finished products storage at +4°C is less compatible with modern life
- To mitigate risk, manufacturers increase the number of strains/CFUs



Is it safe?

Is it cost effective?

Determining the Need for Active Packaging in Probiotics





Do you have a package or device that is tight and has headspace?

3-Phase Activ-Polymer™ Technology: The Solution to These Challenges

Active Material Science Platform Technology

Material Science: Adding Chemistry to Polymers

3-Phase Activ-Polymer™ Material



Active Material Science Platform Technology


Material Science: Adding Chemistry to Polymers

3-Phase Activ-Polymer™ Material



HOW IT WORKS:

- Channels created within a polymer allow movement of gases
- “Active” particles are added to polymer to:
 - **Adsorb** or **Absorb** (moisture)
 - **Scavenge** (gases, odors, reactive impurities, formaldehyde, other VOCs)
 - **Release/Emit** (aromas, biocides, antimicrobials, nutrients, CO₂)
- **Gas diffusion** is controlled through the channel composition
- Allow **high load of active compound** in limited headspace




Active Packaging – Putting Chemistry into Polymers

3-Phase Activ-Polymer™ Material


Allows the **control of kinetics** based upon formulation:

- Uptake rate can be increased or decreased
- Absorption capacity can be increased or decreased
- Buffered RH solutions for products susceptible to over-drying

Moisture Adsorption Kinetics



Oxygen “Pull-Down” Performance





Active Packaging – Putting Chemistry into Polymers

Tightly Sealed Environment

Utilizing **3-Phase Activ-Polymer™** technology requires a **tightly sealed environment**

- Chemistry required determined
- Gas or moisture transmission rates reviewed
- Focus on seals associated with package
- Amount of **3-phase material** required depends on how **tight** of an **environment** it will be placed in



Active Material Science Platform Technology

Ability to incorporate single or multiple chemistries into a polymer solution that retains the performance of the chemistries while maintaining the physical properties of the polymer

Incorporate Desired Chemistry

Moisture Control



Scavenging - Oxygen, CO₂, Ethylene, Formaldehyde



Antimicrobial




Emitters



Odor Removers



Aptar CSP 3-Phase
Activ-Polymer™
PlatformTechnology



Commercial Applications

Injection molding



Thermoforming



Extrusion Film



Extrusion Blow Molding*



Hot melt*




*Applications in development

Probiotics Formulations

Activ-Vial™

Technology Applications


- **CSP™ Flip-Top Activ-Vial™** with integrated 3-Phase Activ-Polymer™ sleeve
- Patented “Close In The Mold” Technology Ensures **Moisture-Tight Seal**
- Maintains seal integrity throughout shelf life and consumer use life
- Child-Resistant/Senior-Friendly Closures
- Screw-Top versions also available



CSP™ Bottles Calculated RH Maintained


64ml and 110ml

Calculated % RH Maintained in 64mL Vial vs. Time 25°C and 60% RH



- Data based on empty containers. Addition of product may impact %RH
 - Data based on CSP's internal testing of bottles for foil seal integrity.
 - Based on minimum capacity and maximum moisture ingress per container
- 64mL Vial


Calculated % RH Maintained in 110 mL Vial vs. Time 25°C and 60% RH




- Data based on empty containers. Addition of product may impact %RH
 - Data based on CSP's internal testing of bottles for foil seal integrity.
 - Based on minimum capacity and maximum moisture ingress per container
- 110mL Vial

CSP™ Bottles RH Maintained

54ml, 78ml, 112ml, 150ml





Humidity Control During Use Life



Probiotics capsules will remain dry during all use life

Probiotic Capsules – Water Activity



(CSP™ *Activ-Vial*™ vs Alu/Alu Blisters)



Study performed in partnership with UAS Labs, a leading probiotic manufacturer.

Probiotic Capsules – Strain Potency



(CSP™ Activ-Vial™ vs Alu/Alu Blisters)



Study performed in partnership with UAS Labs, a leading probiotic manufacturer.

Water Activity in Probiotics + Cranberry



CSP™ Activ-Vial™ vs. Amber Glass with Desiccant



Study performed in partnership with UAS Labs, a leading probiotic manufacturer.

Potency of Probiotics + Cranberry Capsules

CSP™ Activ-Vial™ vs. Amber Glass with Desiccant



Study performed in partnership with UAS Labs, a leading probiotic manufacturer.


3 Years Stability Results

In collaboration with Targedys (France)



Stability results TA1 / EnteroSatys® / Satylia® / Satilia® 36 months

Biomass stability (flow cytometry) at 25°C and 30°C




3 Years Stability Results

In collaboration with Targedys (France)



Stability results TA1 / EnteroSatys® / Satylia® / Satilia® 36 months

Stability in CFU at 25°C and 30°C



Probiotics Formulations Activ-Polymer™ Molded Components

Probiotics Applications: Molded Components

- Can be integral device component (ex: reconstitution cap or straw)
- Adsorbs **moisture, O₂, odors, etc.**
- Maintains very tight dimensional tolerances



Activ-Tab™
Probiotics Oil
Suspension



Bormioli 3 Phase
Probiotics Powder




X-Straw
Drug or Food Supplements
Administration



Probiotic Oil Drops Stability

(CSP™ Molded Activ-Polymer™ vs. Control)



**CSP™ Molded Activ-Polymer™
in graph uses 1 Tablet:**

- 3mm thick x 8mm OD
- 0.2 gram



Data courtesy of




Probiotics Formulations Activ-Blister™ Solutions

Probiotics Application Activ-Blister™ Solutions

- Incorporating 3-Phase Activ-Film™ into blister packaging solutions
- 3-Phase Activ-Film™ heat staked to foil
- Protects product from moisture, oxygen, CO₂, reactive impurities and odors
- **Active headspace protection** achieved without extra steps (e.g. gas flush/purging, secondary packaging, or refrigeration)
- **Size reduction** → move from cold-form foils to thermoforms for a smaller blister footprint (**40-60% smaller**)




Sources of Moisture and Oxygen



Activ-Blister™ Solutions

Results compared to Cold Form Blisters and HDPE Bottles




Activ-Blister™ Solutions

Results of Aclar-type thermoformed blisters + Activ-Film


Aclar® type	Temp/RH (°C/%RH)	Days to saturation
Rx160	25/60	209
Rx160	30/65	71
Rx160	40/75	21
UltRx2000	25/60	370
UltRx2000	30/65	220
UltRx2000	40/75	71
UltRx6000	25/60	1036
UltRx6000	30/65	647
UltRx6000	40/75	209

Assume ~6.6mm x ~13mm x 1mm piece
for Size 0 capsule



Probiotic Capsule Water Activity

(Standard PVC.PvdC Blister Packaging vs. Activ-Blister™ Packaging with CSP Activ-Film™)



Storage Conditions:
22°C ± 2°C
40% ± 5% RH




Data courtesy of



Probiotic Capsule Potency

(Standard PVC.PvdC Blister Packaging vs. Activ-Blister™ Packaging with CSP Activ-Film™)



Storage Conditions:
22°C ± 2°C
40% ± 5% RH




Data courtesy of



Probiotic Stick Pack Water Activity

(CSP™ Activ-Film™ vs. No Activ-Film™, Ambient Conditions)




Data courtesy of



Probiotic Stick Pack Stability

(CSP™ Activ-Film™ vs. No Activ-Film™)



- No Activ-Film™
- Activ-Film™
0.3mm x 15mm x 17.5mm
- Activ-Film™
0.3mm x 15mm x 50mm

Data courtesy of



Thank you for your attention!

François Bidet

VP Business Development

francois.bidet@aptar.com